

**Mounting Configurations**  
(View shown from rear of LED Bar)

3. Mount the LED Traffic Master bracket on the front or rear of the light bar frame as desired. Use either existing holes in the light bar frame, if available, or drill holes as needed.

#### NOTE

Remember to properly seal all holes made in any light bar to prevent water damage.

4. Turn the light bar right side up and attach the LED Traffic Master to its mounting bracket as shown on Page 7. **Use ONLY 5 x 10mm bolts.**
5. Put the light bar on the vehicle roof making sure not to scratch the vehicle. Check for clearance below the light bar as you proceed.
6. Reposition the light bar and secure it to the vehicle.
7. Tighten the bolts that hold the LED Traffic Master mounting bracket to the light bar, checking that the brackets are aligned with each other. Some adjustment of these brackets may be required to insure that the directional signal is level. Adjust as necessary.
8. Position the LED Traffic Master in the center of the vehicle and tighten the bolts that hold it to the mounting bracket.

Fuses should be located as close to the vehicle power takeoff points as possible and properly sized to protect the wiring devices.

### **FAILURE TO FOLLOW THE WARNINGS OR INSTALLATION AND USER INSTRUCTIONS CAN RESULT IN LOSS OF WARRANTY COVERAGE.**

The following installation instructions provide direction for mounting the Traffic Master to most light bar frames. Questions about a specific application should be directed to the **Technical Service Hotline at (800) 338-7337**.


### **PERMANENT MOUNTING**

Prior to mounting, consideration should be given to cable location and lamp replacement. The cable should exit the end cap on the driver's side unless otherwise specified. The lamp module replacement procedure is explained in the Maintenance section of this manual.


### **REAR DECK AND LIGHT BAR MOUNTING**

The LED Traffic Master should be mounted using the adjustable "L" brackets which are provided. Refer to page 7 for specific mounting instructions. In addition, note page 5, relating to mounting configurations and STANDARD or OPTIONAL wiring specification.

1. If a light bar is already mounted on the vehicle, remove the light bar from the vehicle roof and turn it upside down. Rest it on a cloth or some other soft surface. It is not necessary to disconnect the wiring.
2. Select and assemble the adjustable "L" Bracket that fits your specific needs. Standard Bracket - recommended for rear deck and light bar mounting. Heavy Duty Bracket - for use when Traffic Master will be subject to high wind, vibration, and/or severe stress.




**"L" Bracket Assembly**



**NOTE**  
Use 5 x 10mm Bolt **ONLY** when attaching "L" Bracket to the back of the LED Bar.

*Rear Deck Mounting*



**NOTE**  
Use 5 x 10mm Bolt **ONLY** when attaching "L" Bracket to the back of the LED Bar.


*Light Bar Mounting*

## MAINTENANCE

The LED Traffic Master requires little routine maintenance. Occasional cleaning of the lens is all that is required to sustain maximum light output. Use plain water and a soft cloth or lens polish and a very soft paper towel or facial tissue. Since plastic scratches easily, cleaning is recommended only when necessary.

## Changing the LED MODULE

- 1) Determine the location of the nonworking LED module.
- 2) Remove the 4 phillips head screws on the back of the Light Bar that hold the nonworking LED module.
- 3) Gently pull the LED module away from the bar.
- 4) Disconnect the wires from the screw terminals on the back of the LED module. **NOTE:** White wires go to the (+) terminal and the colored wire goes to the (-) terminal.
- 5) Reconnect the wires to the new LED module. **NOTE:** The use of conductive grease on the wire contact is recommended.
- 6) Reattach LED module to Light Bar.



*Changing the LED Module*










# LED Traffic Master

w/ Arrow on Ends  
ETTMLEDDRA



## Installation & Operation Instructions



3900 Central Parkway  
Hudsonville, MI 49426  
toll free 800.338.7337  
office 616.896.7100

techsupport@soundoffsignal.com  
www.soundoffsignal.com