

## 3000 SERIES MAGNET KIT 3000MAKT

**WARNING: High Voltage, Wait 15 Minutes after shutting beacon OFF before converting.**

1. Remove the Beacon Lens and Dress Ring (four screws).
2. Loosen the Strobe Tube Socket Assembly (two screws). Note: Do NOT touch the glass part of the Strobe Tube.
3. Remove the Strobe Circuit Board from the base (three screws).
4. Remove the Red, Black, and Yellow wire harness by unplugging it from the Strobe Circuit Board.
5. Drill a 5/16" hole in the Beacon Base near the outer edge. Note – make sure it clears the magnet.
6. Install the magnet into the center hole of the Beacon base. Insert the 1/4 x 20 bolt through the magnet and up into the beacon base. Put the 1/4 x 20 nut on the bolt and tighten.
7. Insert the terminated ends of the Cigarette Plug wire and the Yellow wire through the 5/16 hole, you drilled, into the Beacon Base so that the terminals end up inside the beacon.
8. Assemble the terminated ends into the Amp. Connector Plug as shown below.
9. Attach the wire tie to the new wire harness about 4 inches down from the Amp. Plug and tighten.
10. Plug Amp. Connector into the Strobe Circuit Board
11. Please refer to the Strobe Beacon Instructions for the proper connecting of the Yellow wire.
12. Reconnect the Strobe Circuit Board to the Beacon Base.
13. Reconnect the Strobe Tube Assembly to the Beacon Base.
14. Reconnect the Beacon Lens and Dress Ring to the Beacon Base.
15. Plug unit in to operate.

