

**BOLT 2 SURFACE MOUNT LIGHT**  
**#E1XS2SME5(xx)**

**INSTALLATION:**

1. Establish a level surface position on the vehicle. Orient the light level to the horizon.
2. Use the screw holes in the assembly as a template to mark locations of the wire and mounting screws.
3. Use a  $\frac{3}{4}$ " (19mm) diameter drill for the wire hole.
4. Size pilot holes for mounting screws appropriately.
5. Fasten light using mounting screws. Do not torque mounting screws beyond 10 in-lbs (1.13 N-m.)

**⚠ WARNING**

This product contains high intensity LED devices. To prevent eye damage, DO NOT stare into the light beam at close range.

800.338.7337 / [www.soundoffsignal.com](http://www.soundoffsignal.com)

FLASH PATTERNS				WIRE HOOK-UP TABLE		
Pattern Name	ECE Pattern	SAE Pattern	CA 13 Pattern	(Flashes / Second)	Wire Color	Connect to:
1. Single	X	X		2.08	RED	+10-30Vdc (Color 1)
2. Double	X	X		2.08	YEL	+10-30Vdc (Color 2)
3. Quad2		X		1.12	BLK	(-) Ground
4. Quint		X		1.18	WHT	Pattern Select +Vdc / Sync
5. PowerPulse		X		3.03	GRN	Dim / Night Mode
6. Road Runner		X	X	1.89		
7. Slow Runner		X	X	1.16		
8. Steady ON				NA		

See website for full installation instructions