

3900 Central Parkway Hudsonville, MI 49426 toll free 800.338.7337 office 616.896.7100 techsupport@soundoffsignal.com www.soundoffsignal.com

## PAR 36 LED LIGHT

E36REBB(x)

A=AMBER, B=BLUE, R=RED, W=WHITE

### **INSTALLATION**

# Remote Flasher Operations:

1. Install the proper 3 Position Amp Connector Housing onto the terminated ends of the Strobe Cable.

#### **NOTE**

WIRING CODE MUST BE OBSERVED WHEN INSERTING PINS INTO AMP CONNECTOR **HOUSING**. Refer to Figure A.

- 2. Mount the "U" Bracket to the Light Housing and then to the vehicle using the supplied parts kit.
- 3. Route the Cable as required.




Figure A.

In remote mode, whenever power is supplied to the Red wire, the Light will be ON. To operate LED Light in this mode connect the wires as follows:

> Black Wire: Ground

Connect to Switched +12Vdc Red Wire:

White Wire: Ground

### **Self Contained Flasher Operations:**

In self-contained flasher mode, whenever power is supplied to the Red wire, the Light will flash the pattern stored in memory. To change the pattern stored in memory, momentarily ground the White wire. When desired pattern is selected, tape the end of the white wire. To operate LED Light in this mode connect the wires as follows:

> Black Wire: Ground

Red Wire: Connect to Switched +12Vdc White Wire: Momentarily ground to change

pattern, then tape end.

### Available Flash Patterns:

Single Flash	180 fpm	Double Flash	70fpm
E-Single	220 fpm	Quad Flash	70fpm
Quint Flash	70 fpm	Single Flash	114 fpm
Warp Flash	350 fpm	Double Flash	140 fpm

#### WARRANTY

Sound Off, Inc. warranties it's LED Vehicle Signaling Products to be free from defects in material and workmanship under normal use for a period of seven (7) years from date of manufacture. LED Products or devices will be considered in warranty when 10% of the total LED diodes within them fail to illuminate properly during the warranty period. Connectors and pigtalis will be warranted for a period of three (3) years if conductive grease or other weather seating compound is used on the connector or pigtali. The start of this period is determined by the date impreinted on the product itself or a label which is adhered to the product. Warranty is extended to the original purchaser of the product, whether this is a manufacturer of the vehicle / equipment in which the Sound Off, Inc. products have been installed or the first consumer of the Sound Off, Inc. product from an authorized agent or dealer and not to any subsequent party. The product must be returned with a copy of the original sales receipt that the user was given to be given claim consideration

This limited warranty shall not be extended to cover Sound Off, Inc. products or any parts thereof in which defects in equipment have been caused by misuse, neglect, unauthorized alterations or repairs, incorrect wiring, water or chemical damage caused by the use of incompatible cleaners, solvents or chemicals. This warranty also does not apply to severe duty applications, such as off-road or construction equipment applications.