

UltraLITE PLUS EXTERIOR LED DIRECTIONAL ARROW PUL3BRM - BACK RACK BRACKET KIT



FIGURE 1.



FIGURE 2.

⚠ WARNING

- HIGH CURRENT interconnects must be properly terminated. Poor crimp quality can cause heat build-up and fire. Follow crimp connector manufacturer instructions.
- DO NOT install this product or route any wires in the Air Bag Deployment Zone. Refer to vehicle Owner's Manual for deployment zones.
- Do NOT use system to disconnect headlights, brake lights or other safety equipment.
- Unit may become hot to touch during normal operation.
- Failure to properly install connectors, fuses or wiring may cause vehicle failure or fire.
- Installation must only be performed by trained technician. Installer must determine vehicle wiring configuration and proper integration of system.
- Use proper wire gauge. All power wires connecting to positive (+) or negative (-) battery terminal or local chassis ground (-) must be sized to supply at least 125% of max. current and properly fused at power source.
- Install protective grommets when routing wire through firewall or metal.

NOTICE:

Installers and users must comply with all applicable federal, state and local laws regarding use and installation of warning devices.

Improper use or installation may void warranty coverage.

To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product, visit our website at www.soundoffsignal.com/tech-services/returns/. If you have questions regarding this product, contact **Technical Services**, Monday - Friday, 8 a.m. to 5 p.m. or after hours 5 p.m. to 8 p.m. ET at 1.800.338.7337 (press #4). Questions or comments that do not require immediate attention may be emailed to techservices@soundoffsignal.com.

INSTALLATION INSTRUCTIONS

1. Mark 11.5" from the top point on the back rack.
2. Attach the bracket to the back rack by drilling in the (4) self-tapping screws to the designated location.

NOTE: The brackets being screwed into the back rack cannot be more than 35" apart.

3. Thread the nuts onto the T-bolts about 3 thread lengths; make sure there is enough thread left to slide the arrow onto the bracket.

NOTE: Arrow should be mounted with wire on Driver Side.

4. Align the T-bolts with the slots on the brackets attached to the back rack. Slide the T-bolts into the slotted holes.
5. While the nuts are still loose, slide the arrow back and forth until the arrow is centered on the back rack.
6. Tighten down the T-bolts using a 3/8" wrench.
7. Plug in the harness to the arrow.

**SoundOff
Signal**

1.800.338.7337 / www.soundoffsignal.com

SUPERIOR CUSTOMER RELATIONSHIPS. SMARTLY DESIGNED LIGHTING & ELECTRONIC SOLUTIONS.

UltraLite Plus Arrow Back Rack 0519