


nFORCE LED INTERIOR LIGHTBAR

2018-2019 DODGE DURANGO REAR



△ WARNING

- HIGH CURRENT interconnects must be properly terminated. Poor crimp quality can cause heat build-up and fire. Follow crimp connector manufacturer instructions.
- DO NOT install this product or route any wires in the Air Bag Deployment Zone. Refer to vehicle Owner's Manual for deployment zones.
- Do NOT use system to disconnect headlights, brake lights or other safety equipment.
- Unit may become hot to touch during normal operation.
- Failure to properly install connectors, fuses or wiring may cause vehicle failure or fire.
- Installation must only be performed by trained technician. Installer must determine vehicle wiring configuration and proper integration of system.
- Use proper wire gauge. All power wires connecting to positive (+) or negative (-) battery terminal or local chassis ground (-) must be sized to supply at least 125% of max. current and properly fused at power source.
- Install protective grommets when routing wire through firewall or metal.

INSTALLATION:

 Align and center the included drill template onto the centerline of the vehicle, matching the template to the rear, plastic fascia. Temporarily, secure in place with non-marking tape.

Continue installation instructions on page 2.

CONTAINS		
ITEM #	QTY	COMPONENT
1	3	2" Shroud Standoffs
2	3	1/4" Size - 3" Self Drilling Screw
3	1	Rear Interior Shroud
	1	2018+ Durango Rear ILB Template
	1	Installation Instruction Sheet
	1	Product Warning Card



NOTICE:

Installers and users must comply with all applicable federal, state and local laws regarding use and installation of warning devices.

Improper use or installation may void warranty coverage.

To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product, visit our website at www.soundoffsignal.com/tech-services/returns/.

If you have questions regarding this product, contact Technical Services, Monday - Friday, 8 a.m. to 5 p.m. or after hours 5 p.m. to 8 p.m. ET at 1.800.338.7337 (press #4).


Questions or comments that do not require immediate attention may be emailed to techservices@soundoffsignal.com.

SUPERIOR CUSTOMER RELATIONSHIPS. SMARTLY DESIGNED LIGHTING & ELECTRONIC SOLUTIONS.





nFORCE LED INTERIOR LIGHTBAR 2018-2019 DODGE DURANGO REAR









INSTALLATION (cont.):

- 2. Scribe the drill locations indicated by the template. See Fig. 2
- 3. Remove plastic fascia then drill as indicated. Remove template after drilling all three holes. See Fig. 3

NOTE: Only drill through the plastic fascia.

- 4. Connect the shroud to the 3-wire harness ran into the hatch.
- 5. Fit the shroud into the vehicle, aligning the shroud holes with the newly created holes in the plastic fascia. Insert the plastic standoffs into the holes making sure not to pinch any wires. See Fig. 4
- Insert the supplied self-tapping screws into the plastic standoffs. Tighten the screws to 12 in-lb, seating the screw into the hatch sheet-metal. Do not over tighten the self-tapping screws.
 See Fig. 5

OPERATION:

See 'Electrical Installation' section of the nFORCE® LED Interior Lightbar installation packet.

NOTICE:

Installers and users must comply with all applicable federal, state and local laws regarding use and installation of warning devices.

Improper use or installation may void warranty coverage.

To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product, visit our website at www.soundoffsignal.com/tech-services/returns/. If you have questions regarding this product, contact Technical Services, Monday - Friday, 8 a.m. to 5 p.m. or after hours 5 p.m. to 8 p.m. ET at 1.800.338.7337 (press #4).

Questions or comments that do not require immediate attention may be emailed to techservices@soundoffsignal.com.

SUPERIOR CUSTOMER RELATIONSHIPS. SMARTLY DESIGNED LIGHTING & ELECTRONIC SOLUTIONS.

SoundOff Signal IIIIII